




where inspiration flows


ORIGINS



Installation Guide
Bath shower mixer with shower kit

This instruction booklet covers these models:
ORI-230+K-CP, ORI-230+K-CPK.

ORI-230+K-CP
ORI-230+K-CPK



Vado
Wedmore Road, Cheddar, Somerset, England BS27 3EB
tel 01934 744466. fax 01934 744345
aftersales@vado.com
www.vado.com



Important - please read

Please read these instructions carefully before starting installation and keep for future reference.

Remove all packaging and check the product for missing parts or damage before starting installation.

Any alterations made to this product and fittings may infringe water regulations and will invalidate the guarantee.

The installation must comply with all Local/National Water Supply Authority Regulations/Byelaws and Building and Plumbing Regulations.
To be installed in accordance with BS EN806.

We strongly recommend that you use a qualified and registered plumber.

General installation

This fitting is a mixing device and therefore water supplies should be reasonably balanced.

When installed, the fitting must comply with the requirements of the Water Supply (Water Fittings) Regulations 1999 and Scottish Byelaws 2004.

For further information, contact the Water Regulations department of your local water supplier (see the WRAS website www.wras.co.uk for details) or the Water Regulations Advisory Scheme by email (info@wras.co.uk) or telephone: 01495848454.

Before making any inlet pipe connections, all supply pipes MUST be thoroughly flushed to remove debris. Failure to do so could result in damage or low flow from the mixer unit. Water Supply (Water Fittings) Regulations 1999 Schedule 2 Section 13.

The fitting of isolating valves to the inlet feeds is advised for ease of maintenance.

Please take great care when installing this mixer not to damage its surface.

Please note if installing in an enclosed environment, access should be left for servicing and maintenance. No costs relating to inadequate access can be accepted.

Please note: installation for the ORI-230+K-CP is shown throughout this guide, please follow the same instructions to install the ORI-230+K-CPK.

Operating Specifications

Operating Pressure


Minimum operating pressure **1 bar**

Maximum operating pressure **5 bar**


Contents of Packaging



Installation guide & User manual



Mixer with O-rings



Fixing Kit

Handset Holder


Rubber washers x 2



Nuts x 2



Hex key



Holder and bracket




Wall plugs x 2

Screws x 2




Handset






Shower hose with 2 washers






Dimensions




Installation - Quick guide



Installation - Quick guide



Installation



Before installing your new mixer, flush through the pipe work to ensure removal of debris, turn off the water supply.

Position both O-rings into the bottom of the mixer body.

Position the mixer on the bath. From the underside of the bath fit the rubber washers and nuts. Tighten the nuts to clamp the mixer to the bath.

CAUTION: Do not over tighten the nuts as this may damage the bath.

Connect the water supply to the inlet pipes. The hot water should be connected to the left hand pipe and cold to the right.

Place a rubber washer into the nut end of the hose and attach it to the mixer outlet.

Installation




⚠ Warning! Please check for any hidden pipes and cables before drilling holes in the wall.

If you are fitting the unit to a partition wall or a wall of particularly soft substrate you will need specialist fixings..

Unscrew the bracket from the holder.

Select the position for the shower bracket and offer the bracket to the wall, mark the 2 fixing points with a suitable pencil. Remove the bracket from the wall, drill two 6mm diameter holes to the depth required. Insert the wall plugs and secure the bracket to the wall ensuring it is perfectly straight using the screws provided.

Screw the holder onto the bracket, making sure that the taper is pointing downwards, to match the cone on the shower hose.




Installation

Handset

Place one of the rubber washers into the cone end of the hose and screw to the handset.

Place the handset into the holder.



Notes:

Notes: