




where inspiration flows

WATERGAMES


Installation and Operation Guide
Cistern flush plates



This instruction booklet covers these models:

WG-195-RO, WG-195-SQ
(CP, MB, MW and SBR finish options)

WG-195-RO
WG-195-SQ



Vado
Wedmore Road, Cheddar, Somerset, England BS27 3EB
tel 01934 744466 fax 01934 744345
aftersales@vado.com
www.vado.com



Important - please read

VADO reserves the right to make technical improvements and enhance the appearance of the products included in this instruction manual.

Please read these instructions carefully before starting installation and keep for future reference.

Remove all packaging and check the product for missing parts or damage before starting installation.

Any alterations made to this product and fittings may infringe water regulations and will invalidate the guarantee.

The installation must comply with all Local/National Water Supply Authority Regulations/Byelaws and Building and Plumbing Regulations.

To be installed in accordance with BS EN806.

We strongly recommend that you use a qualified and registered plumber.


Please take great care when installing this product not to damage its surface.

Cleaning instructions



The coating on this product is finished to the highest standard. Due care needs to be taken to ensure the appearance is retained.

We recommend cleaning all products with a soft damp cloth **ONLY** and advise strongly against the use of all aggressive/corrosive cleaning products i.e. powders and liquids. If these instructions are not followed, this may invalidate your guarantee in the event of a problem occurring.




Contents of Packaging





Dimensions






Installation








Installation






Installation - standard cistern








Installation - standard cistern






Installation - short cistern





Installation - short cistern






Installation





Installation







Installation



Operation







Maintenance Standard Cistern



Maintenance Short Cistern

Notes:



Notes:

Notes: